

INSTRUCTIONS

5 CLICKS ON/OFF

CLICK THE BUTTON 5 TIMES TO ACTIVATE!

2 CLICKS PREHEAT

TO START PREHEAT, CLICK BUTTON 2 TIMES. PREHEAT WILL TAKE 15 SECS AND COLORFUL LIGHTS WILL FLASH.

3 CLICKS VOLTAGE

TO CHANGE VOLTAGE SETTINGS, CLICK BUTTON 3 TIMES.



INCLUDED

⚡ 350mAh ⚡ BATTERY

USB CHARGER



CHARGING
BLINKING



CHARGED
SOLID

FEATURES

- Rechargeable Variable Voltage Battery
- Button Activated
- Easy-to-Use Design



UNIVERSAL
510-THREAD



MICRO USB-CABLE
INCLUDED



BUTTON
ACTIVATION



PREHEAT
FUNCTION